

Calithrex 15 years dedicated to electric heated towel racks Calithrex Product Model EA7-700 Installation&After-Sales Service	Table of Contents Important Safety Instructions Packing List Control Panel Description Installation Instructions Plug-in Installation Hardwired Installation Basic Parameters After-Sales Service&Support 01 02 03 04 07 08 09 09 IMPORTANT SAFETY INSTRUCTIONS Safety in Use: Do not completely wrap the heated towel rack with bath towels or other fabrics for more than 8 hours, as this will block heat dissipation, affect product lifespan. Maintain air circulation on both sides of the product The product is completely enclosed	Calithrex 1.Packing List Wall Bracket 1 x4 Expansion Screw Assembly 2 x4 Installation Template 3 x1 Instruction Manual 4 x1 Connecting Rod for Wiring 5 x1 Connecting Rod 6 x3 Screw 7 x4 M4*70mm Screw 8 x6 M5*7mm Screwdriver 9 x1 Power Plug 10 x1 Top Storage Rack 11 x1 2	Calithrex 2.Control Panel Description Led 1 Led 2 Led 3 150 Temperature (99-150°F) Timing (1-24hours ,H) On/Off Power On/Off When in standby mode, LED1 pulses with a breathing light effect while the digital display remains off. Press the Power button to turn on the device. Once powered on, the display shows the set temperature or timer value, and LED1, LED2, and LED3 illuminate. To power off, press the Power button again. LED1 will resume the breathing effect, and the display will turn off. Temperature Setting When powered on, press the Temp button; the display will flash to indicate temperature adjustment mode. Press Temp repeatedly to cycle through values: 99 → 102 → ... → 150 → 99. If no button is pressed for 5 seconds, the display stops flashing and the setting is saved automatically. Timer Setting When powered on, press the Timer button to view the current timer setting. If no timer is set, the display shows "--". Press Timer again to cycle through: 1h → 2h → 3h → 4h → ... → 24h → H (continuous mode). The setting is saved automatically after 5 seconds of inactivity, and the display will show the remaining time. 3	Calithrex 3.Installation Instructions Step 1: Position the mounting template on the wall to mark drilling points, then drill holes using an M6 drill bit. Recommended Mounting Height 4	Calithrex 3.Installation Instructions Step 2: Insert expansion screws (2) or drywall anchors (2) Step 3: Secure the Connecting Rod (6) to the main body using screw (7). 5	Calithrex 3.Installation Instructions Step 4: 1.Mount the wall brackets (1) to the wall using the screw assemblies (2). 2.Insert the connecting rods (6) into the wall brackets (1). 3.Secure the screws (8) into the brackets (1) using the screwdriver (9). 4.Tighten or fix the connecting rods (6) in place. Step 5: 1.Determine the power cord exit direction for the heated towel rack(bottom left or bottom right), then thread the power cord (10)through the Connecting Rod for Wiring (5), insert the plug into the port and rotate to secure.
---	--	--	--	---	---	--

6